Lift Wax-Free Furniture Polish

7 LIFT



Easily removes a variety of soils, such as grease and finger marks.

Wax-free formulation to prevent build-up of waxes on surfaces.



2 x 5L | 052392X5

A unique wax-free formulation, that offers superior cleaning whilst leaving a durable, high-gloss finish. Ideal for use on a wide variety of surfaces such as paintwork, enamel, laminates and sealed wooden surfaces. Designed to effectively remove a wide variety of soils such as dust and finger-marks leaving only a deep, long-lasting shine.

Also, available as a 5L refill pack for greater economy.

Not suitable for use in food preparation areas.



6 x 750ml | 057827

Directions for use

For professional use only.

Do not use on waxed or lacquered furniture.

- 1. Open the nozzle on the spray head.
- 2. Spray the product sparingly onto a soft, clean, dry cloth.
- 3. Allow to dry for a few seconds, then apply to the surface and polish to a shine.



Dispense into a heavy duty refill flask using a 5L tap dispenser.



6 x 750ml | 056553/6

Product Info

Colour: White

Fragrance: **Aromatic**

pH: **5.5 - 6.5**

Shelf Life: 24 Months

