

Lift Graffiti Remover



Easily removes
paint and inks
from a variety of
surfaces.

Suitable for use
on a wide range
of hard surfaces.

Low odour
formulation.

A low odour emulsifiable graffiti remover, designed to remove aerosol spray paint, marker pen and ballpoint from stone, plastic, metal and brickwork. Suitable for use on stainless steel, chrome, ceramics, marble, limestone, and other natural stones, enamel, aluminium, brass, copper and textiles.



6 x 750ml | 057666

Product Info

Colour: **Colourless**

Fragrance: **Solvent**

pH: **N/A**

Shelf Life: **24 Months**

Directions for use

For professional use only.

Always test on an inconspicuous area before cleaning, to ensure product compatibility.

1. Apply to the surface to be cleaned.
2. Leave to activate for 3-5 minutes.
3. Scrub away manually with a stiff brush and water or remove via a pressure washer.
4. Rinse with clean water to remove any excess product.

CLEENOL

Tel: +44(0) 1295 251 721

Email: sales@cleenol.co.uk

Neville House, Beaumont Road, Banbury, Oxon. OX16 1RB.

Cleenol Group Ltd is a limited company registered in England and Wales under CRN 00635803.